



INSTRUCTION MANUAL

Model AMCSG27PW

Please read this instruction manual before using your new multi cooker

The warranty repair slip is valid with the receipt of purchase, so it is recommended to keep it

DEAR CUSTOMER

Thank you for choosing our product

The pressure cooker is exceptionally easy to use and extremely efficient. After reading the instruction manual, operating the pressure cooker will be easy.

Before being packaged and leaving the manufacturer, the pressure cooker was thoroughly checked with regard to safety and functionality.

Before using the appliance, please read the instruction manual carefully.

By following these instructions carefully you will be able to avoid any problems in using the appliance.

Contents

Safety Precautions.....	4
Name and Function of Each Part	5
Specifications	6
Preparation Instructions Before Use.....	7
Warm Tips for Various Functions	9
Cleaning and Maintenance.....	9
Fault and Treatment Method	10
Аюулгүйн зааварчилгаа.....	14
Үзүүлэлтүүд.....	15
Хэрэглэхийн өмнө бэлтгэх заавар	17
Эвдрэл гэмтэл засварлах заавар	19

Safety Precautions

Please read this manual carefully before use

- This product is only for household use and not suitable for other places.
- The socket with a rated current of more than 10A with grounding must be used, and the plug should be inserted tightly. Do not use the universal socket with other electrical appliances at the same time.
- When the plug is inserted into the socket, it must be inserted to the bottom, otherwise the component will be overheated and burnt out due to poor contact.
- Do not plug the plug with wet hands to avoid electric shock. When the product is not in use, please unplug the power plug
- Do not place the product in the reach of children or let children use it alone to avoid electric shock or scald.
- It is forbidden to insert metal chips, iron wire, needle and other foreign matters in the product or gap, otherwise electric shock or abnormal operation will be happened.
- When using this product, it must be placed on a stable table. Do not use this product in high temperature and high humidity places. Keep away from inflammables.
- This product is not suitable for the following people: people with sensory or psychological dysfunction, people without relevant experience or knowledge (including children). Unless they use this product under the supervision and guidance of professionals, children should be taken care of to ensure that they do not play with the product.
- Ensure that the power cord does not come into contact with sharp edges, burrs, other protruding sharp objects or objects with high surface heat, which may cause electric leakage, electric shock or fire
- Odor may appear for several minutes at the first use, which is normal.
- Only the inner pot attached to this product can be used, and cannot be replaced by other manufacturers or other inner pots, so as to avoid product failure or danger.
- Do not start the operation before the inner pot is put into the pot or when the inner pot is empty

- The inner pot cannot be heated on other furnaces, otherwise it will be damaged easily.
- Do not put any food or water in the pot before putting it into the pot.
- Do not remove the inner pot when the product is working, so as to avoid danger.
- Keep hands and face away from steam holes to prevent scalding.
- Do not cover the steam hole with dishcloth or other items, so as to avoid deformation of the uppercover and product failure.
- Before putting the inner pot into the rice cooker, please confirm whether there are rice grains or other vegetable dregs on the bottom and on the inner pot. If so, please remove them before putting them into the inner pot, otherwise the components will be burnt out due to poor contact with the inner pot.
- Make sure that the inner pot fits tightly with the inner pot after putting it in.
- If the inner pot is damaged, please do not continue to use it. Contact our after-sales service personnel to purchase a new inner pot.
- When cleaning the product, do not immerse the product in water or wash under the tap.
- Repair the cord with a dedicated cord or replace it from the manufacturer if the cord is broken or replaced.
- In case of any fault of this product, please turn off the power supply and pull out the plug from the socket. Do not continue to use it. Contact the after-sales service personnel of our company. Do not replace non original parts or disassemble and repair by yourself.

Name and Function of Each Part



Products with accessories

rice cooker	Inner pot	ladle	a soup spoon	Measuring cup	steamer	power cord	instructions
1 set	1	1	1	1	1	1	a copy

Specifications

Model	AMCSG27PW
Rated power supply	230V~50/60Hz
Rated power	860W
Rated capacity	5L
Boiled rice (cup)	2-10 people
Suitable number of people	2-10 people

Operation Interface

Function : Press the "function" button to select pilaf, fried, soup, milk porridge, steaming, yogurt, cake, custom, the corresponding indicator light will flash, press the "start" button to enter the cooking state.

cooking state.

Preset: pilaf, soup, milk porridge, cooking, yogurt, cake, any one of the functions, press the appointment key, according to the required time, press the hour and minute key to adjust the time, after selection, press the "start" button, the rice cooker enters the reservation cooking state.

Warm tips: some functions cannot use the reservation function

To set the appointment time, press the reservation key to enter the reservation adjustment state

--Press + /- key to adjust the time

--The maximum appointment time can be adjusted to 24 hours

--In order to prevent food from stinking in water for a long time, the appointment time should not exceed 12 hours

--If the time set by appointment is less than the cooking time, the rice cooker will not enter the reservation state, but directly enter the set function to start working

--After setting, press and hold the "start" key to confirm and start the reservation cooking function

Hour/minute :

In the functional cooking time and the appointment time selection mode, adjust the working time according to the needs.

Warm tips: cooking time of some functions cannot be adjusted

Keep warm/Cancel :

Press this key in standby mode to enter the keep warm mode, the "keep warm" indicator light is on, and the digital tube displays the heat preservation time. In the cooking state, press the "Cancel" key to cancel the current function and enter the standby mode. When you choose rice function and the rice cooker start to cook

, then you found need to choose porridge not rice function, press this button, cancel the rice function

then you can choose the porridge one, correct the function you need. If you need to keep warming, press 3 seconds then the cooking will keep warming.

Start:

After selecting the desired cooking function, press the "start" button to start the work

After the selection function is completed, the buzzer "Di", "Di" sounds several times to prompt that

the cooking is completed, the rice cooker automatically enters the heat preservation state, the heat preservation indicator light is on, and the screen displays the heat preservation time

Preparation Instructions Before Use

■ make sure that the steam valve is installed correctly. If the steam valve is not installed, the steam valve will overflow

■ Clean and weigh the rice

--The measuring cup is about 150g

--Do not wash directly in the inner pan

■ The maximum cooking rice quantity 5L is 10 cups of rice. According to your actual needs, it is suggested that the ratio of rice to water should be 1 cup rice / 1.2 cups of water. You can also add water according to the scale line. For example, when cooking 2 cups of rice, put the washed rice into the pot and add water to the corresponding 2 scales. Do not exceed the maximum rice cooking amount (the ratio of rice to water can be adjusted according to personal preference and rice species)

--The maximum marked water level in the boiler shall not exceed

■ Before putting the inner pot into the rice cooker, please make sure whether there are rice grains or other vegetable dregs on the bottom of the inner pot and the heating plate. If there is, be sure to remove them before putting them into the inner pot. After putting them, make sure that the inner pot fits tightly

Reference Table for Cooking Time of Each Function

Function	Optional time range	Remarks
Pilaf	0:10—2: 00	--
Frying	0:10—1:30	This function cannot be used for preset cooking
Soup	1:00-4:00	--
Milk porridge	0:30-2:00	--
Steam	0:05-1:30	When the water boils, the countdown begins
Yogurt	6:00-12:00	--
Cake	1:00—2:00	--
DIY	1:00—12:00	--

Warm Tips for Various Functions

1. The cooking times describe ed in the table above will vary slightly according to the voltage, rice quantity, water quantity, water temperature and rice quality. In order to prevent the rice from caking and not delicious, please loosen the rice within 30 minutes after entering the heat preservation state.
2. When cooking, the effect is better when the rice pot is turned to heat preservation and stewed for 15 minutes.
3. The maximum amount of porridge cooking function is 1.5 cups, and the recommended ratio of porridge to water is 1:8.
4. The maximum amount of porridge is 1.5 cups, and the recommended ratio of porridge to water is 1:10.

Cleaning and Maintenance

1. Clean the inner pot and sealing cover with hot water, detergent and sponge. Do not use detergent and steel ball.
2. Clean the bottom of the pan before soaking.
3. Please don't put the rice into the pot to avoid damage.
4. Clean the middle ring, sealing cover and outside of the cooker with a wet cloth
5. If there is water on the heating plate, please dry it with a rag. If there is burnt rice grain, please use steel ball or sandpaper to polish it
6. Please clean the sealing cover and steam valve regularly to avoid the peculiar smell of rice.
7. When not in use for a long time, the plug should be pulled out from the socket and stored in a ventilated and dry place.

8. Before cleaning the product, please make sure that the power plug has been pulled out of the powersocket, and wait until it is completely cooled before cleaning the product to prevent scalding.

Fault and Treatment Method

When the following abnormal phenomena occur during use, it is not entirely the fault of the machine.

Please check it carefully before sending it out for maintenance.

It is strictly forbidden to dismantle and repair without authorization except for repair technicians.

Fault phenomenon	Causes	resolvent
The indicator light doesn't work	The power is not connected	Check whether the product is plugged in tightly
	Circuit board failure	Contact with the company's customer service personnel
The whole machine is not heated	Circuit board failure	Contact with the company's customer service personnel
	Heating plate failure	
	The fuse is burnt out	
Indicator light is not on	Heating plate failure	Contact with the company's customer service personnel
	Circuit board failure	

	Cook too much or too little	Adjust the total capacity of meter and water from the maximum to the minimum scale
	The ratio of rice to water is wrong	Adjust the ratio of rice to water

under-do	The inner pot is not placed well, hanging in the air	Put the inner pot well and press it down gently to make it return to normal
	There is foreign matter between the inner pan and the heating plate	Remove the foreign matter
	The pot is damaged	Contact the customer service personnel of our company to purchase new inner pot
	Circuit board failure	Contact with the company's customer service personnel
	Sensor failure	Contact with the company's customer service personnel
Boiled rice	The pot is damaged	Contact the customer service personnel of our company to purchase new inner pot
	The inner pot is not placed well, hanging in the air	Put the inner pot well and press it down gently to make it return to normal
	Circuit board failure	Contact with the company's customer service personnel
	Sensor failure	Contact with the company's customer service personnel
	Excessive cooking	Adjust the amount to moderate
	The ratio of rice to water is	Reduce the amount of water

overflow	not suitable	
	incorrect function	Choose the right function
Flavored plastics	Normal phenomenon	After several times of use, the rice cooker will not taste
Error code displayed on digital screen:	Circuit board or sensor failure	Pull out the power plug first. If the cooker still fails after cooling down, contact the
E1, E2, E3, E4		company's customer service personnel



ГАРЫН АВЛАГА

Модел AMCSG27PW

Уг бүтээгдэхүүнийг ашиглахаасаа өмнө доорх зааварчилгаатай танилцана уу

Баталгаат засварын хуудас нь худалдан авалтын баримтын хамт хүчинтэй тул хадгалахыг зөвлөж байна

Аюулгүйн зааварчилгаа

Хэрэглэхийн өмнө энэ гарын авлагыг анхааралтай уншиж танилцана уу

- Уг бүтээгдэхүүн нь зөвхөн ахуйн хэрэглээнд зориулагдсан бөгөөд бусад газарт тохиромжгүй.
- Газардуулгатай 10А-аас дээш гүйдэлтэй залгуурыг ашиглах ба залгуурыг сайтар залгах шаардлагатай. Олон залгуур болон бусад цахилгаан хэрэгсэлтэй нэгэн зэрэг ашиглаж болохгүй
- Залгуурыг тэгш гадаргуун дээр тавьж залгах хэрэгтэй ба эс тэгвээс эд анги нь барьснаас болж хэт халж шатах эрсдэлтэй.
- Тог цахилгаанаас сэргийлэхийн тулд залгуурыг нойтон гараар бүү залгаарай. Бүтээгдэхүүнийг ашиглаагүй үед цахилгааны залгуурыг салгана уу
- Тог цахилгаан түлэгдэхээс сэргийлж бүтээгдэхүүнийг хүүхэд хүрэх газар бүү тавь.
- Бүтээгдэхүүн эсвэл цоорхойд металл төмөр утас, зүү болон бусад гадны биетүүдийг оруулахыг хориглоно. Эс бөгөөс цахилгаанд цохиулах, бүтээгдэхүүн эвдрэх эрсдэлтэй.
- Уг бүтээгдэхүүнийг хэрэглэхдээ тогтвортой ширээн дээр тавих ёстой. Энэ бүтээгдэхүүнийг өндөр температур, чийгшил ихтэй газар бүү хэрэглээрэй. Шатамхай бодисоос хол байлга.
- Энэ бүтээгдэхүүн нь дараах хүмүүст тохиромжгүй: мэдрэхүйн болон сэтгэл зүйн эмгэгтэй хүмүүс, холбогдох туршлага, мэдлэггүй хүмүүс (үүнд хүүхдүүд). Тэд энэ бүтээгдэхүүнийг мэргэжлийн хүмүүсийн хяналт, зааварчилгаан дор хэрэглэнэ. Хүүхдийг уг бүтээгдэхүүнээр тоглохоос болгоомжлох хэрэгтэй.
- Цахилгааны утсыг хурц ирмэг, хагархай, хурц объект, гадаргуу өндөр халдаг зүйлтэй ойр байлгавал, гал түймэр үүсгэж болзошгүйг анхаарна уу.
- Анхны ашиглахад хэдэн минутын турш үнэр гарч болзошгүй бөгөөд энэ нь хэвийн үзэгдэл юм.
- Зөвхөн энэ бүтээгдэхүүнд хавсаргасан дотоод савыг ашиглах боломжтой бөгөөд бусад үйлдвэрлэгчид болон бусад дотоод савнуудаар сольж болохгүй, ингэснээр бүтээгдэхүүний гэмтэл, аюулаас зайлсхийх боломжтой.
- Дотор савыг авах эсвэл дотор сав хоосон байхад үйл ажиллагааг эхлүүлэхгүй байх хэрэгтэй.
- Дотор савыг бусад зууханд халаах боломжгүй, эс тэгвээс амархан гэмтэх болно.
- Саванд хийхээсээ өмнө саванд ус, хоол хийж болохгүй.

- Аюулаас зайлсхийхийн тулд бүтээгдэхүүн ажиллаж байх үед дотоод савыг бүү гарга.
- Түлэгдэхээс сэргийлж гар нүүрээ уурын нүхнээс хол байлга.
- Уурын нүхийг аяга тавагны алчуур болон бусад зүйлээр хааж болохгүй, ингэснээр дээд бүрхүүлийн хэв гажилт, бүтээгдэхүүн эвдрэхээс сэргийлнэ.
- Дотор савыг будаа агшаагч руу хийхээсээ савны өмнө ёроол болон дотор талд будааны үр тариа эсвэл бусад ногооны үлдэгдэл байгаа эсэхийг шалгана уу. Хэрэв тийм бол хийхээсээ өмнө тэдгээрийг салгаж авна уу, эс тэгвээс эд ангиуд нь шатах эрсдэлтэй
- Дотор савыг тавьсны дараа дотор савтай нягт таарч байгаа эсэхийг шалгаарай.
- Дотор сав нь гэмтсэн бол цаашид бүү ашигла. Шинэ сав худалдаж авахын тулд манай борлуулалтын ажилтнуудтай холбогдоно уу.
- Бүтээгдэхүүнийг цэвэрлэхдээ усанд дүрж, цоргоны доор угааж болохгүй.
- Хэрэв залгуур тасарсан эсвэл солигдсон бол утсыг тусгай утсаар засварлах эсвэл үйлдвэрлэгчээс солих хэрэгтэй.
- Энэ бүтээгдэхүүнд ямар нэгэн гэмтэл гарсан тохиолдолд цахилгаан тэжээлийг унтрааж, залгуурыг залгуураас сугалж авна уу. Үүнийг үргэлжлүүлэн хэрэглэж болохгүй. Манай компанийн борлуулалтын ажилтнуудтай холбогдоорой. Оригинал бус эд ангиудыг сольж болохгүй, өөрөө задалж, засварлаж болохгүй.

Бүтцийн нэр, үүрэг

Дагалдах хэрэгсэл бүхий бүтээгдэхүүн

Будаа агшаагч	Дотор сав	Шанага	Шөлний халбага	Хэмжүүрийн сав	Жигнүүр	Залгуур	Тайлбар
1 багц	1	1	1	1	1	1	Хуулбар

Үзүүлэлтүүд

Загвар	AMCSG27PW
Цахилгаан хангамж	230V~50/60Hz
Эрчим хүч	860W

Хүчин чадал	5л
Будаа агшаах хэмжээ	2-10 хүн
Тохиромжтой хүний тоо	2-10 хүн

Үйлдлийн самбар

Функц: "Функц" товчийг дарж пилаф, шарсан хоол, шөл, сүүтэй будаа, жигнүүр, тараг,

бялуу, зэргээс сонгоход гэрэл анивчих болно. "Эхлэх" товчийг дарж эхлүүлнэ.

Урьдчилан тохируулга: Пилаф, шөл, сүүтэй будаа, тараг, бялуу зэргийг хийхээр аль нэг функцийг сонгохдоо цаг товлох товчийг дарж, шаардлагатай цагийн дагуу цаг, минутын товчлуурыг дарж цагийг тохируулна. Сонголтоо хийсний дараа "эхлэх" товчийг дарахад будаа агшаагч захиалсан төлөвт ордог.

Зөвлөгөө: Зарим функцууд захиалгын функцийг ашиглах боломжгүй

Цаг тохируулахын тулд захиалсан товчлуурыг дарж захиалгын сонгосон төлөвийг оруулна уу

--Цаг тохируулахын тулд + /- товчийг дарна уу

--Хамгийн их цагийг 24 цаг болгож тохируулах боломжтой

--Хоол хүнсийг усанд удаан хугацаагаар муутгахгүйн тулд 12 цагаас хэтрүүлэхгүй байх шаардлагатай.

--Тогтоосон цаг нь хоол хийх хугацаанаас бага байвал будаа агшаагч захиалгын төлөвт орохгүй, харин тохируулсан функц руу шууд орж ажиллаж эхэлнэ.

--Тохируулсны дараа "эхлэх" товчийг удаан дарж, захиалга хийх хоол хийх функцийг баталгаажуулж, эхлүүлнэ үү

Цаг/минут:

Энгийн ажиллагааны цаг эсвэл тохируулсан цаг сонгохдоо хэт удаан цаг тааруулахгүй байвал тохиромжтой.

Зөвлөгөө: Зарим функцээр хоол хийх хугацааг тохируулах боломжгүй

Халуун байлгах/Цуцлах

Энэ товчлуурыг дарснаар халуун барих горимд орох ба "Халуун барих" гэрэл асаж дижитал дэлгэцэн дээр хугацааг харуулна."Цуцлах" товчийг дарж одоогийн функцийг цуцална. Та будааны функцийг сонгоод будаа агшаагч ажиллаж эхлэх ба будааны функцийг ашигласны дараа шаардлагатай функцийг засах боломжтой. Хэрэв та халаах шаардлагатай бол 3 секунд дарвал хоол халах болно.

Эхлэх:

Хоол хийх функцийг сонгосны дараа "Start" (эхлэх) товчийг дарж ажлаа эхлүүлнэ үү
 Сонгох функц дарснаар "Di", "Di" дуугаралт хэд хэдэн удаа сонсогдоно
 Хоол хийж дуусахад будаа агшаагч автоматаар дулаан хадгалах төлөвт орж,
 дулаан хадгалах заагч гэрэл асснаар дэлгэц дээр дулаан хадгалах хугацааг
 харуулна.

Хэрэглэхийн өмнө бэлтгэх заавар

■ Жигнүүрийг зөв суурилуулсан эсэхийг шалгаарай. Хэрэв буруу тогтоосон бол хоол түүхийрэх бүрэн болохгүй байх эрсдэлтэй.

■ Цагаан будааг цэвэрлэж, хэмжүүрийн аяга ашиглах заавар.

--Хэмжүүрийн аяга-150мг

--Будааг зөвхөн дотор зориулалтын саванд угаана уу

Хоол хийх будааны дээд хэмжээ 5л нь 10 аяга будаа юм. Будаа ба усны харьцаа нь 1 аяга будаа / 1.2 аяга ус байх ёстой. Мөн масштабын шугамын дагуу ус нэмж болно. Жишээлбэл, 2 аяга будаа чанахдаа угаасан будаагаа саванд хийж, тохирох усыг хийнэ. Будаа бэлтгэх дээд хэмжээнээс хэтрүүлж болохгүй (будаа ба усны харьцааг хувийн сонголт, будааны төрлөөс хамааран тохируулж болно)

Бойлер дахь усны хамгийн их тэмдэглэгдсэн түвшин нь хэтрэхгүй байх ёстой

Функц бүрийн хоол хийх цаг хугацааны заавар

Функц	Хугацаа	Тайлбар
Пилаф	0:10—2:00	
Шарах	0:10—1:30	Энэ функц нь цаг тохируулалгүйгээр хоол хийхэд тохиромжтой.
Шөл	1:00-4:00	--

Сүүтэй будаа	0:30-2:00	--
Бүх төрлийн хоол хийх	0:05-1:30	Ус буцалснаар хоол хийж болно.
Тараг	6:00-12:00	--
Бялуу	1:00—2:00	--
Үндсэн хоол	1:00—12:00	--

Төрөл бүрийн функцүүдэд зориулсан зөвлөмжүүд

- Дээрх хүснэгтэд тодорхойлсон хоол хийх хугацаа нь хүчдэл, будааны хэмжээ, усны хэмжээ, усны температур, будааны чанараас хамаарч бага зэрэг ялгаатай байна. Будаа жигнэхээс сэргийлж, амттай биш байхын тулд дулаан хадгалах төлөвт орсноос хойш 30 минутын дотор будаагаа суллана уу.
- Хоол хийхдээ будааны савыг халааж, 15 минутын турш чанаж болгосон нь илүү үр дүнтэй байдаг.
- Хоол хийх функцийн хамгийн дээд хэмжээ нь 1.5 аяга бөгөөд ус хийх харьцаа нь 1:8 байна.
- Будааны дээд хэмжээ 1,5 аяга байх ба будаа, ус 1:10 харьцаатай байхыг зөвлөж байна.

Цэвэрлэгээ, засвар үйлчилгээ

- Дотор сав, битүүмжлэлийн тагийг халуун ус, угаалгын нунтаг, хөвөнгөөр цэвэрлэнэ.
- Угаалгын нунтаг болон ширүүн төмөр хэрэглэж болохгүй.
- Дотор савыг хэрэглэхээсээ өмнө савны ёроолыг цэвэрлэнэ үү.
- Дотор савыг ашиглахгүйгээр хоол хийж болохгүй.
- Савны дотор болон битүүмжлэх таг түүний дотор талыг нойтон даавуугаар цэвэрлэнэ.
- Хэрэв халаалтын хавтан дээр ус байгаа бол өөдөсөөр хатаана уу. Хэрэв будаа шатсан бол түүнийг өнгөлөхийн тулд ган бөмбөлөг эсвэл зүлгүүр ашиглана уу

- Цагаан будааны өвөрмөц үнэрээс зайлсхийхийн тулд битүүмжлэх таг болон уурын хавхлагыг тогтмол цэвэрлэж байгаарай.
- Удаан ашиглаагүй тохиолдолд залгуурыг залгуураас татаж, агааржуулалттай, хуурай газар хадгална.
- Бүтээгдэхүүнийг цэвэрлэхийн өмнө цахилгааны залгуурыг цахилгааны залгуураас сугалж авсан эсэхийг шалгаад, түлэхээс сэргийлж цэвэрлэхийн өмнө бүрэн хөргөхийг хүлээнэ үү.

Эвдрэл гэмтэл засварлах заавар

Ашиглалтын явцад дараах хэвийн бус үзэгдлүүд тохиолдоход энэ нь бүхэлдээ төхөөрөмжийн буруу биш юм.

Засвар үйлчилгээнд явуулахаасаа өмнө сайтар шалгана уу.

Засварын техникчээс бусад зөвшөөрөлгүйгээр задлах, засварлахыг хатуу хориглоно.

Гэмтэл	Шалтгаан	Шийдэл
Заагч гэрэл ажиллахгүй байна	Эрчим хүч холбогдоогүй байна	Бүтээгдэхүүнийг сайтар холбосон эсэхийг шалгана уу
	Хэлхээний самбар эвдэрсэн	Компанийн харилцагчийн үйлчилгээний ажилтнуудтай холбоо барина уу
Машиныг бүхэлд нь халаахгүй	Хэлхээний самбар эвдэрсэн	Компанийн харилцагчийн үйлчилгээний ажилтнуудтай холбоо барина уу
	Халаалтын хавтангийн эвдрэл	
	Гал хамгаалагч шатсан байна	
Заагч гэрэл асаагүй байна	Халаалтын хавтангийн эвдрэл	Компанийн харилцагчийн үйлчилгээний ажилтнуудтай холбоо барина уу
	Хэлхээний самбар эвдэрсэн	

Саваа дутуу хийх	Хэт их эсвэл хэт бага хоол хийх	Тоолуур ба усны нийт багтаамжийг дээд хэмжээнээс хамгийн бага хуваарь болгон тохируулна
	Будаа ба усны харьцаа буруу байна	Будаа ба усны харьцааг тохируулна уу
	Дотор савыг сайн байрлуулаагүй байна.	Дотор савыг сайтар тавиад зөөлөн дарж хэвийн байдалд оруулна
	Дотоод тогоо ба халаалтын хавтангийн хооронд гадны зүйл байна	Гадны бодисыг гаргана.
	Сав гэмтсэн байна	Шинэ дотоод сав худалдаж авахын тулд манай компанийн харилцагчийн үйлчилгээний ажилтнуудтай холбоо барина уу
	Хэлхээний самбар эвдэрсэн	Компанийн харилцагчийн үйлчилгээний ажилтнуудтай холбоо барина уу
	Мэдрэгчийн эвдрэл	Компанийн харилцагчийн үйлчилгээний ажилтнуудтай холбоо барина уу
Будаа агшаах	Сав гэмтсэн байна	Шинэ дотоод сав худалдаж авахын тулд манай компанийн харилцагчийн үйлчилгээний ажилтнуудтай холбоо барина уу
	Дотор савыг сайн байрлуулаагүй байна.	Дотор савыг сайтар тавиад зөөлөн дарж хэвийн байдалд оруулна
	Хэлхээний самбар эвдэрсэн	Компанийн харилцагчийн үйлчилгээний ажилтнуудтай холбоо барина уу
	Мэдрэгчийн эвдрэл	Компанийн харилцагчийн үйлчилгээний ажилтнуудтай холбоо барина уу
Хэтэрхий дүүргэх	Хэт их хоол хийх	Хэмжээг дунд зэрэг тохируулна уу
	Будаа ба усны харьцаа тохиромжгүй	Усны хэмжээг багасгах
	Функцын буруу сонголт	Зөв функцийг сонго
Хуванцарын амт	Ердийн үзэгдэл	Хэд хэдэн удаа хэрэглэсний дараа амт нь арилах болно
Алдааны кодыг харуулав. Дижитал дэлгэц: E1, E2, E3, E4	Хэлхээний самбар эсвэл мэдрэгч эвдэрсэн	Эхлээд цахилгааны залгуурыг сугалж ав. Хэрэв хөргөсний дараа эвдэрсэн хэвээр байвал компанийн харилцагчийн үйлчилгээний ажилтнуудтай холбоо барина уу