



INSTRUCTION MANUAL

Model AMCSG38PSB

Please read this instruction manual before using your new multi cooker

The warranty repair slip is valid with the receipt of purchase, so it is recommended to keep it.

DEAR CUSTOMER

Thank you for choosing our product

The multicooker is exceptionally easy to use and extremely efficient. After reading the instruction manual, operating the multicooker will be easy.

Before being packaged and leaving the manufacturer, the multicooker was thoroughly checked with regard to safety and functionality.

Before using the appliance, please read the instruction manual carefully. By following these instructions carefully you will be able to avoid any problems in using the appliance.

Contents

Specification table of product	4
Safety precautions	4
Instructions before use	5
Operation Interface.....	6
Бүтээгдэхүүний үзүүлэлт	12
Аюулгүй ажиллагааны заавар	12
Хянах самбар	14
Цэвэрлэгээ	17
Хэрэглээнээс гарсан хуучин цахилгаан бараа хаягдал, устгал	19

Specification table of product

Model	AMCG38PSB
Voltage	220V 50Hz
Power	860W
Capacity	5L
Suitable	2-10 Person

Safety precautions

- Please read the instruction manual carefully before using, and save it properly.
- This product is only used for family.
- Rated current must be used with more than 10 A with ground socket, plug in to pay attention to tight. Do not use the multi-purpose socket used with other electrical appliances.
- When plug the socket, make sure is tight, or the components will be burned, as bad contact cause it too heat.
- Don't use wet hand use plug, in order to avoid electric shock, do not put power cord plug jack when don't use.
- Don't put the product in the children can contact with the local, or kids to use alone, in order to avoid electric shock or burns.
- Prohibited put the insert scrap metal, iron wire, needles and foreign body into inside the product or crack, otherwise it will cause electric shock or abnormal work.
- When using this product must be placed on a smooth table to use, and do not use this product in high temperature and high humidity. and away from combustible materials.
- This product is not applicable to the following: sensory or mental impairment, and lack of relevant experience or knowledge (including children) and so on. Unless they are in the professional under the supervision of the use of the product. Should take care of children, to ensure that they do not play this product.
- Make sure the power cord with sharp edges, burrs, and other prominent sharp objects or hot items contact surface, which may cause leakage, electric shock or fire.
- Used for the first time there may be a few minutes smell, belongs to the normal phenomenon.
- Only the original inner pot can be used, other inner pot can't replace, avoiding any trouble and danger.
- Don't start to open when you don't put inner pot body or inner pot is empty
- Don't put rice cooker above beside source of heat & fire, or rice cooker will be damaged, even generate dangerous.
- Don't put anything including water food on the body, when inner pot hasn't been put.
- Don't move inner pot when rice cooker is working.
- In the processing of cook, or food will produce steam and high temperature, please keep

away rice cooker.

- Don't put rag or other things cover the steam outlet when using, in case cause the lid out of shape or stoppage.
- Please check if anything stick on the heating plate and bottom of inner pot before using. if has, you must clean it, otherwise it will burn out heating plate with pot components due to poor contact.
- After putting the inner pot into body, please turn around in order to make sure there is close between inner pot and heating plate.
- Inner pot if there is any breakage, please do not continue to use,, you should send to "repair service center" to buy the new one.
- Don't soak body into water, also don't make into body.
- If you find broken or damaged power cord or plug, have to use special cord or purchase the special component replacement from the manufacturer or the appointed maintenance department.
- If produce is out of order, please switch off the power first, And the pull out the plug from the socket, please don't unset the product, and contact our "repair service center", don't replace the parts which is not the origin, and don't repair by yourself.

Instructions before use

- Confirm the steam valve installed correctly, if begin cooking without installed the steam valve, there may be a liquid overflow.
- Use measuring cup weighing the rice, wash that
A measuring cup of rice is about 150g. Don't wash the rice in the inner pot directly.
- The largest rice amount of 5L is 10 cups.

According the actual amount required rice, suggest the proportion of rice: water is 1 :1.2, and can according the tick add water, For exam-ple, wash 2 cups of rice, and then put that into inner pot, add the water to the tick of "2", Do not exceed the maximum amount of the proportion rice and water (the proportion of water can be based on personal preferences and adjusted it by user)

Shall not exceed the highest water level of inner pot.

- Please check if anything stick on the heating plate and bottom of inner pot, clean it before using. After putting the inner pot into body, please turn around in order to make sure there is close between inner pot and heating plate.

Operation Interface



Function button:

Rotating "Function" button, and choose the function of the corresponding: Rice cook, Fast cook, Soaked rice, Crust, Porridge, Soup, Steam, Stew, Pasta, Pizza, Multifunction, Oatmeal, Milk Porridge, Yoghurt, Fry, Baby food, Slow cook, Bake, Bread, Cake, Reheat the corresponding light is lit up, and then long press the "start" button for 2 seconds rice cooker into cooking.

Multifunction button: On the standby state, press this button to quickly enter the multifunction selection state.

Time button:

Press this button to enter time adjusting state, according to individual need to adjust the cooking time function. Warm prompt: work part time cannot adjust.

TEMP button:

Press this button to enter the function state of temperature adjustment, according to individual needs, working temperature of rotating button to adjust matters.

Preset button: choose the function of the corresponding: Rice Cook, Porridge, Soup, steam, Stew, Baby Food, Slow Cook Choose any one function/hour and press the "preset" button, enter into preset time and adjust the cooking time for min/hour, and then long press the "start" button for 2 seconds rice cooker into preset cooking state.

Preset time Settings:

- Press the preset button, into the preset adjustment status.
- Press "Time" button adjust the hour time.
- Adjust the longest preset time is 24 hours.
- To prevent food for a long time of soaking in the water produce peculiar smell, make an preset time had better not exceed 12 hours
- If the preset time is less than the cooking time, rice cooker would not enter the preset function, the function will be directly to work which the same like without preset.
- After setting, long press " start "button for 2 seconds quickly into crust state, make sure enter the presser function.

Hour/minute button:

Cooking time to choose the function model and preset mode, adjust the working time according to your specific needs.

Warm prompt:

1. part functions cannot adjust the time.
2. According to the need to press the Time button to switch back and forth minute/hour.

Keep warm button/ Cancel button:

- On the standby state, long press "keep warm" for 2 seconds quickly into keep warm state, keep warm time the longest is 24 hours, after the keep warm time to enter standby mode automatically.
- On the cooking state, press "cancel button " for 2 seconds, Cancel the current function, enter standby mode.

Start button:

- Choose the required function, long press the "start" button for 2 seconds, rice cooker begin to work
- After setting function, Buzzer "di" "di" "di" number of chirping sound finish cooking, the product enter into keep warm state.(Yoghurt function directly enter into standby state after finish function), the screen would show the keep warm time.

Cook time table for function

Function	Time range	Remark
Rice Cook	--	The largest amount of cooking time about 50 minutes
Fast cook	--	The largest amount of cooking time about 55 minutes
Soaked rice	0:20 - 1 :30	--
crust	1 :00 - 2:00	--
Porridge	1 :00 - 4:00	--
Soup	1 :00 - 4:00	--
steam	0:05 - 1 :00	--
Stew	2:00 - 6:00	--
pasta	0:05 - 1 :00	--
pizza	0:30 - 1 :30	--
multi funtion	0:10 - 12:00	Have temperature options
Oatmeal	0:30 - 1 :30	--
Milk Porridge	1 :00 - 4:00	--
Yoghurt	0:10 - 12:00	Returns the standby state after the function finish
Fry	0:30 - 1 :30	Have temperature options
Baby Food	1 :00 - 4:00	--
Slow Cook	2:00 - 6:00	--
bake	0:30 - 1 :30	--
cake	0:50 - 2:00	--
reheat	0:20 - 1 :00	--
bread	0:30 - 1 :30	1 hour and 15 minutes before work for fermentation, after 1 hour and 15 minutes of baking

Tips for functions

- Described cooking time in the above table, it would be according to the voltage, rice, water, water temperature, rice quality have slightly different. To prevent rice agglomeration; please turned loose rice after enter the keep warm state within 30 minutes.
- When cooking, turn keep warm function with 15 minutes, the taste would be more better.

Rice:

- The largest rice amount 5L is 1 .5 cups of rice porridge function, suggest the proportion of rice: water is 1 :8 of Porridge function.
- The maximum water levels should not exceed 70% of the inner pot capacity with Soup/Stew function
- The maximum number of yogurt should not be more than 1100 ml.
- In the rice surface evenly sprinkle 1/2 cups water with reheat function rice, the taste more better.

Soup:

Ingredients: half of chicken, 25g of red jujube, 20g of longan, 15g of medlar, 20g of ginger, salt.

- The raw materials processed in accordance with the specifications.
- Rinse chicken slices, put the ginger, jujube, longan together into the pot.
- After 35 minutes put into the medlar.
- Finally add a little salt.
- Cover and choosing "soup" function, after that can be enjoyed.
- Can be based on what the actual material, choose the appropriate time to cooking.

Yoghurt:

Ingredients: 100 ml original yogurt (or 1 g of Bifido bacterium), 1000 ml of pure milk, one or more of the sealed container.

The production process:

- Clean up the sealed container, (keep container dry and clean)
- Add pure milk in the container, add the yogurt (or bifidbacteria), with a spoon to stir to mix well.
- Cover the lid, put into the rice cooker pot, choose yogurt function, according to the preferences to adjust time (6 to 12 hours), long press the start button for 2 seconds into the working status, finish function would be into standby mode directly.
- Open the container lid, you can see yogurt is like the bean curd flower, other ingredients can be added according to the habit of user.

Tip: the proportion of yogurt with pure milk is 1: 10, the proportion of bifido bacterium and pure milk is 1 g: 1 L, pot directly.

Stoppage	Reason	Methods of Solving
Indicator unlights	power doesn't switch on	Check rice cooker if unplug
	Power board damaged	Send to "Repair Service Centre"
Heating plate unheated	Power board damaged	Send to "Repair Service Center"
	Heating plate damaged	
	Fuse damaged	
Indicator lights, heating plate unheated	Heating plate damaged	Send to "Repair Service Center"
	Power board damaged	
Rice under cooked	The capacity of rice too less or too much	Adjust the proportion of rice and water, range between the max & min scale line
	he proportion of rice and water is wrong.	Adjust the proportion of rice and water
	Inner pot oblique	Put in the pot is good, gently press down, make it back to normal
	A foreign body between the pot and the heating plate	Clear up the foreign body
	Inner pot broken	Contact the "Repair service centre" to buy the new inner pot.
	Power board damaged	Send to "Repair Service Center"
	Sensor damaged	Send to "Repair Service Center"
Rice over cooked	Inner pot broken	Contact the "Repair service center" to buy the new inner pot.
	Inner pot oblique	Put in the pot is good, gently press down, make it back to normal
	Power board damaged	Send to "Repair Service Center"
	Sensor damaged	Send to "Repair Service Center"
Overflow	The capacity of rice too much	Adjust the proportion of rice and water
	The proportion of rice and water is wrong.	Reduce the amount of water
	Choose wrong function	Choose the correct function
Smell of plastic	Normal condition	Rice cooker after using a few times, the smell will not
Screen show: E1, E2, E3, E4	Power board or sensor damaged	To pull the plug, rice cooker is still fail after cooling, contact the company customer service department

Asaya

ХЭРЭГЛЭГЧИЙН ГАРЫН АВЛАГА

Модел код AMCSG38PSB

Хэрэглэхээс өмнө зааварчилгаатай сайн танилцана уу

Баталгаат засварын хуудас нь худалдан авсан барааны төлбөрийн баримтын хамт хүчинтэй тул анхаарч, хадгалахыг зөвлөж байна.

ХҮНДЭТ ХЭРЭГЛЭГЧ ТАНАА

Манай бүтээгдэхүүнийг сонгосон танд баярлалаа.

Бүтээгдэхүүнээс авах сэтгэл ханамжийг нэмэгдүүлэх, хэрэглэгчийн аюулгүй байдал болон бүтээгдэхүүний зөв хэрэглээ, гарч болзошгүй эвдрэл гэмтлийг засварлах талаарх мэдээллийг бүтээгдэхүүн суурилуулж угсрахаас өмнө гарын авлагаас уншиж танилцан, гарын авлагыг цаашдын хэрэглээнд зориулан хадгална уу.

Бүтээгдэхүүний хэрэглэхэд хялбар, хөнгөн байдал, авсаархан загвар, дизайн зэрэг давуу талууд нь таньд таатай байдлыг мэдрүүлэх болно.

Бүтээгдэхүүний үзүүлэлт

Загвар	AMCG38PSB
Хүчдэл	220В~50Гц
Хүчин чадал	860Вт
Багтаамж	5 л
Багтаамж	2-10 аяга
Зориулалт	2-10 хүн

Аюулгүй ажиллагааны заавар

- Будаа агшаагчийг цахилгаанд залгахын өмнө хүчдэл хэвийн байгаа эсэхийг нягтална уу.
- Энэхүү бүтээгдэхүүн нь зөвхөн гэрийн хэрэгцээнд зориулагдсан бөгөөд нийтийн зориулалтаар ашиглах нь тохиромжгүй.
Уртасгагч залгуур хэрэглэх болон олон цахилгаан бараатай ХАМТ залгах нь эрсдэлтэй.
- Нойтон гараар залгуураас барих, цахилгаанд залгаж болохгүй, цахилгаанд цохиулах эрсдэлтэй.

Хэрэглэхийн өмнө цахилгааны утас нь залгуурт залгагдсан эсэхийг шалгана уу.

Хүнгүй үед будаа агшаагчийг асаалттай орхиж болохгүй

Бага насны хүүхэд болон хөгжлийн бэрхшээлтэй иргэд бие даан ашиглахыг хориглоно. Ашиглах тохиолдолд асран хамгаалагчийн заавар зөвлөгөөний дагуу хэрэглэнэ.

- Чийгтэй , тохиромжгүй нөхцөлд хэрэглэж болохгүйснаас хол байлгана уу.
- Дотор савыг хийгээгүй байхдаа эсвэл дотор сав хоосон байх үед ажиллуулж болохгүй.
- Ханын залгуурт залгах нь тохиромжтой, гүйцэд сайн бэхлэх шаардлагатай.
- Хэрэглэхийн өмнө будаа агшаагчны цахилгааны утас нь их биед сайтар бэхлэгдсэн байх ёстой.

- Будаа агшаагч ажиллаж байх үед дотор савыг гаргаж болохгүй
- Будаа агшаагчтай хамт үйлдвэрээс ирсэн зориулалтын тогоог ашиглана уу.
- Хэт халуун болон гал гарч болзошгүй газар будаа агшаагчийг тавихаас зайлсхийнэ үү. Будаа агшаагч гэмтэх, шатах аюултай.
- Дотор савыг зориулалтын бусаар халааж болохгүй /Ил гал болон цахилгаан зуух дээр ашиглахгүй байх/.
- Дотор савыг хийгээгүй байхдаа ус, хоол хүнс будаа агшаагчинд хийж болохгүй. Дотор саванд зааврын дагуу зориулалтын хэмжигчээр усбудаа хийнэ.
- Будаа агшаагч ажиллаж байх үеийн өндөр температурт металл хэсгүүдэд хүрч болохгүй.
Будаа агшаагч ажиллаж байх үед халуун уур гарах тул хол байх хэрэгтэй
- Дотор савны хязгаарлагч шугамаас давуулж ус, хоол хийхээс зайлсхийнэ үү'
- Цахилгааны утсыг татах, түлхэх замаар салгаж авахгүй байна уу.
- Будаа агшаагчинд ямар нэгэн доголдол үүссэн тохиолдолд, цахилгаанаас салгана уу. Эвдэрч гэмтсэн тохиолдолд мэргэжлийн засварчнаас засуулна уу.

Хэрэглэхийн өмнө анхаарах зүйлс

Та анх удаа хэрэглэх гэж байгаа бол гарын авлагыг сайтар уншиж танилцаад, зааврын дагуу ашиглана уу.

Дагалдах хэрэгсэл болон бусад хэвлэмэл зүйлсийг дотроос нь гаргана
Нээх товчлуурыг дарж тагийг нээнэ

Дотор сав, жигнүүр болон хөнгөн цагаан тагийг салгаж авна

Угаалгын бодис бүхий хөвсгөр хөвөн даавуугаар дотор сав, жигнүүр болон халихаас хамгаалах хөнгөн цагаан тагийг арчиж цэвэрлэнэ.
Угаасны дараа хуурай алчуураар арчиж хатаана

Уур гадагшлуулах хавхлага зөв суурилсан эсэхийг шалгана уу. Хавхлага буруу суурилагдсан бол хавхлагаар шингэн халих эрсдэлтэй.

Хэмжих аяга нь 150 гр бөгөөд зориулалтын хэмжих аягаар будаа, усны хэмжээг тохируулна уу. Будааг будаа агшаагчны тогоонд шууд угааж болохгүй.

битүү чанах, гоймон, пицца, овъёос, сүүтэй будаа, тараг, шарах, хүүхдийн хоол, удаан болгох, жигнэмэг, талх барих, бялуу, дахин халаах гэсэн функцуудаас сонгоод ‘Урьдчилсан тохиргоо’ товчлуурыг дарна. Хэдэн цагийн дараа хоол бэлтгэж эхлэхийг болон хоол бэлтгэх хугацааг тус тус тохируулсны дараа ‘Эхлэх’ товчлуур дээр 2 секунд дарж процесс эхэлнэ.

Хоол бэлтгэж эхлэх хугацааны тохиргоо хийх:

- ‘Урьдчилсан тохиргоо’ товчлуур дээр дарна.
- ‘Цаг’ товчлуур дээр дарж цагийг тохируулна
- Хамгийн ихдээ 24 цагийн тохиргоо хийх боломжтой.
- Хоол удаан хугацаанд усанд дэвтсэнээр амт чанаргүй болох эрсдэлтэй тул урьдчилсан цагийн тохиргоог 12 цагаас хэтрүүлэхгүй байхыг зөвлөж байна.
- Тохиргоог хийсний дараа ‘Эхлэх’ товчлуур дээр 2 секунд дарахад професс явагдаж эхэлнэ.

Санамж: Урьдчилсан цагийн тохиргоо нь хоол бэлтгэх хугацаанаас бага бол хоол шууд бэлтгэгдэж эхэлнэ. Иймд урьдчилсан цагийн тохиргоог хоол бэлтгэх хугацаанаас ихээр тохируулна.

ХАЛУУН БАРИХ / ЦУЦЛАХ ТОВЧЛУУР

‘Халуун барих/ цуцлах’ товчлуур дээр 2 секунд дарснаар шууд халуун барих горимд шилжинэ. Хамгийн ихдээ 24 цаг хүртэл халуунаа барина. Халуун барих хугацаа дууссаны дараа автоматаар унтарна.

ЭХЛЭХ ТОВЧЛУУР

Тохирох функцээ сонгоод ‘Эхлэх’ товчлуур дээр 2 секунд дарсанаар будаа агшаагч ажиллаж эхэлнэ. Будаа агшаагч хоолыг бэлтгэж дууссаны дараа дуугарч, дохио өгөх бөгөөд автоматаар халуун барих горимд шилжинэ. (Тараг бүрэх тохиргоог тохируулсан бол халуун барих горимд шилжихгүй).

Хоол бэлтгэх хугацаа

Функц	Хугацаа	Тайлбар
Будаа	--	Хамгийн их хугацаа 50 мин
Түргэн болгох	--	Хамгийн их хугацаа 50 мин
Дэвтээсэн будаа	0:20-1:30	--
Шаржигнуур	1:00-2:00	--
Хүүхдийн будаа	1:00-4:00	--
Шөл	1:00-4:00	--
Жигнэх	0:05-1:00	--
Битүү чанах	2:00-6:00	--

Гоймон	0:05-0:30	--
Пицца	0:30-1:30	--
Олон үйлдэл	0:10-12:00	Температурын тохиргоотой
Овьёос	0:30-2:00	--
Сүүтэй будаа	1:00-4:00	--
Тараг	6:00-12:00	--
Шарах	0:30-1:30	--
Хүүхдийн хоол	1:00-4:00	--
Удаан болгох	2:00-8:00	--
Жигнэмэг	0:30-1:30	--
Бялуу	0:30-1:30	--
Талх барих	0:30-3:00	--
Дахин халаах	0:20-1:00	--

Санамж: Дээр дурьдсан хугацаа нь будаа, хоолны орц, ус, усны температур, будааны чанар зэргээс хамаарч өөрчлөгдөж болно. Будааг бөөгнөрч нялцайхаас сэргийлж халуунаа барих функц ажиллаад 30 мин болсоны дараа будааг аягална уу. Процесс явагдаж дууссаны дараа автоматаар халуун барих горим ажиллаж эхлэх ба автоматаар ажилласан халуун барих горим 8 цаг хүртэл ажиллана.

БУДАА

- Хамгийн дээд тал нь 10 аяга будаа агшаана. Ус болон будааны тохиромжтой харьцаа нь 1 аяга будаанд 1.2 аяга ус ноогдох хэмжээ юм. Өөрийн хүссэнээр тохируулж болно.
- Зутан төрлийн хүүхдийн будаа, сүүтэй будаа зэрэгт будаа усны харьцаа байвал тохиромжтой.
1:8
- Заагдсан хэмжээнээс их хэмжээгээр будаа агшаах нь тохиромжгүй. Дээд тал нь будаа агшаагчны багтаамжны 70% хүртэл ус хийх нь тохиромжтой.

ШӨЛ

- 'Шөл' гэсэн товчлуур дээр дарна. Ингэхэд шууд ажиллаж эхэлнэ.

Процесс явагдаж дууссаны дараа автоматаар халуунаа барих горимд шилжинэ.

Санамж: Дотор савны хязгаарлагч шугамаас давуулж ус, хоол хийхээс зайлсхийнэ үү.

ТАРАГ

- Хамгийн ихдээ 1100 мл тараг бүрэх боломжтой.
1000 мл цэвэр сүүнд 100 мл тарагны хөрөнгө хийх харьцаагаар тараг бүрнэ
Өөрөөр хэлбэл тараг цэвэр сүүний харьцаа 1:10 байна.
Тараг бүрэхдээ тараг бүрэх битүүмжлэлтэй саваа бэлтгэнэ үү .
- Битүүмжлэлтэй саванд цэвэр сүү дараа нь тарагны хөрөнгөө хийж хутгана.
Битүүмжлэлтэй савны тагийг сайтар таглаж, будаа агшаагчны тогоонд хийнэ.
Тараг бүрэх функцийг сонгож, цагийг тохируулна (6-12 цаг хүртэл), эхлэх товчлуур дээр 2 секунд дарснаар проффесс эхэлнэ.
Тохируулсан хугацаа дууссаны дараа автоматаар унтарна .
- Тараг бүрж дууссаны дараа хүссэн орцоо нэмж хийх боломжтой.

Цэвэрлэгээ

- Хөвөн алчуур, угаалгын бодис бүхий халуун усаар хамгаалалтын давхарга дотор сав, хөнгөн цагаан таг болон жигнүүрийг цэвэрлэнэ. Халбага, хусуур хэрэглэж болохгүй.
- Хэрэв дотор савны ёроолд хоолны үлдэгдэл наалдсан бол цэвэрлэхээсээ өмнө усанд дэвтээнэ, хусаж арилгаж болохгүй.
- Их биеийг усанд булхуулах, дотор нь ус хийх хориотой.

Дотор савны хамгаалагч бүрхүүлийг гэмтээхгүйн тулд хуванцар болон модон халбага ашиглах нь зүйтэй. Металл халбага хэрэглэх нь тохиромжгүй.

Дотор саванд цагаан цуу хийж болохгүй

Их биеийг шууд усаар угааж болохгүй .

- Угаалгын бодис хэрэглэлгүйгээр чийгтэй алчуураар их биеийн гадаргуу, тагны дотор тал, залгуур зэргийг арчиж цэвэрлэнэ.

Гэмтэл	Шалтгаан	Шийдвэрлэх
Заагч гэрэл асахгүй байх	<ul style="list-style-type: none"> Удирдлагын самбарт цахилгаан очихгүй байх Удирдлагын самбар эвдэрсэн байх 	<ul style="list-style-type: none"> Чанагчыг цахилгаанд залгасан эсэхийг шалгана уу Засварын төвд хандана уу
Халаагч таваг халахгүй байх	<ul style="list-style-type: none"> Удирдлагын самбар эвдэрсэн байх Халаагч таваг гэмтсэн Халаагч тавагны тог хүлээн авагч гэмтсэн 	Засварын төвд хандана уу.
Мэдрэгч гэрэл ассан ч халаагч таваг халахгүй байх	<ul style="list-style-type: none"> Халаах таваг гэмтсэн Халаагч таваг залгагдаагүй Халаагч тавагны тог хүлээн авагч гэмтсэн 	Засварын төвд хандана уу.
Хоол түүхийрэх	<ul style="list-style-type: none"> Хэрэглэж буй хүнсний хэмжээ их эсвэл бага 	Дотор савны доод дээд хязгаарт тохируулан хүнсний бүтээгдэхүүнээ хийнэ үү.
	<ul style="list-style-type: none"> Халаагч таваг далийсан 	Засварын төвд хандана уу.
	<ul style="list-style-type: none"> Дотор сав хазайсан 	Дотор савыг эргүүлж халаагч тавагны мэдрэгч ажиллаж байгаа эсэхийг шалгана уу.
	<ul style="list-style-type: none"> Халаагч таваг дотор сав хоёрын голд ямар нэг зүйл орсон 	Ус хэрэглэлгүйгээр их биеийг цэвэрлэнэ үү.
	<ul style="list-style-type: none"> Дотор сав эвдэрсэн 	Засварын төвд хандана уу.
	<ul style="list-style-type: none"> Тог хүлээн авагч гэмтсэн 	Засварын төвд хандана уу.
	<ul style="list-style-type: none"> Температур мэдрэгч гэмтсэн 	Засварын төвд хандана уу.
Хоол хэт болох, түлэгдэх	<ul style="list-style-type: none"> Хэрэглэж буй хүнсний хэмжээ их эсвэл бага 	Дотор савны доод дээд хязгаарт тохируулан хүнсний бүтээгдэхүүнээ хийнэ үү.
	<ul style="list-style-type: none"> Тог хүлээн авагч гэмтсэн Температур мэдрэгч гэмтсэн 	Засварын төвд хандана уу.
Халих, дэврэх	<ul style="list-style-type: none"> Хэт их ус хийсэн 	Усны хэмжээг тохируулна уу.
Дэлгэцэн дээр дараахь алдааг заавал: E1, E2, E3, E4	<ul style="list-style-type: none"> Халаагч тавагны тог хүлээн авагч гэмтсэн 	Засварын төвд хандана уу.

Хэрэглээнээс гарсан хуучин цахилгаан бараа хаягдал, устгал

Цахилгаан болон электрон тоног төхөөрөмжийн хог хаягдал (Waste Electrical and Electronic Equipment 'WEEE') 2002/96/EC -ын Европ дахь удирдлагууд дараах байдлыг тодорхойлсон байна.

Хуучин цахилгаан барааны хог хаягдлыг энгийн хог хаягдалтай хольж хаяж болохгүй бөгөөд энэ нь байгаль орчны болон хүрээлэн буй орчин, эрүүл мэндэд сөргөөр нөлөөлөх хүчин зүйлийн нэг учир эдгээр хохирлыг багасгахын тулд хуучин цахилгаан барааны хог хаягдлыг хотын хог хаягдлаас ялгаж тусад нь устгалд оруулж байх мөн хуучин цахилгаан барааны эд ангиуд дахин ашиглагдах материалд ордог тул тусад нь ялгаж ашиглаж болох хэсгүүдийг дахин ашиглах боломжтой гэж үзнэ.



Энэхүү тэмдэглэгээ нь таны худалдан авсан ахуйн хэрэгцээний цахилгаан болон электрон бараа дээр байвал уг барааг хаях үедээ тусад нь ялгаж байх гэсэн тэмдэг юм.

